



## How to setup Dongle on DSL-G2562DG

1. Please ensure that the dongle is compatible with the router  
[https://downloads.d-link.co.za/DSL/DSL-G2562DG%20\(Telkom\)/compatibility%20list/DSL-G2562DG%20USB%20dongle%20Compatibility%20List.pdf](https://downloads.d-link.co.za/DSL/DSL-G2562DG%20(Telkom)/compatibility%20list/DSL-G2562DG%20USB%20dongle%20Compatibility%20List.pdf)
2. Ensure the SIM is placed in the dongle correctly
3. Plug the Dongle in the USB port located on the back of the router



4. Check under Status > WAN > Dongle, status will show “Up” if the dongle is detected



5. Check the setting for the Dongle under Basic Setup > WAN Service > Edit for Dongle



6. Check the APN settings,

Telkom sim:

TelkomInternet Any

other sim: internet

Rain sim: rain (only works if the Dongle itself supports 4G) And APPLY

WAN Service

Connection Name: Dongle

Enable: ☒

MTU: 1492

IP Protocol Type: IPv4 ▼

NAT: ☒

Firewall: ☒

IPv4 Static DNS: ☐

PIN:

APN: TelkomInternet

7. Restart the router for settings to apply

8. Check under Status > WAN > Network > under IPv4 WAN Connection Status >

Connection name: Dongle > Status

Connected: Internet is working correctly

Connecting: router is busy connecting to internet

Disconnected: please restart router

Note:

Internet light will flash Red/Green when dongle connects to internet