

[Basic Manual Setup for DWR-957X- How to change APN settings]

Step 1: Open your web browser and type **10.0.0.2** into the address bar, then press Enter.



If your device is connected to the router, it will take you to a blue D-Link page asking for a username and password. Default Username is admin, password is admin, unless it was updated.



Step 2: Once logged in, navigate to

Basic Setup → WAN Service



Step 3: Here you will see a table with three options, look for the one that says LTE and then click on edit

WAN ServiceInfo

WAN Name	Interface	Mode	IP Protocol Type	Service Type	Action	
DHCP_WAN_ETH	ETH1	DHCP	IPv4&6	TR069_INTERNET_VOIP	Edit	Delete
PPPoE_WAN_ETH	ETH1	PPPoE	IPv4&6	TR069_INTERNET_VOIP	Edit	Delete
LTE	LTE	DHCP	IPv4	TR069_INTERNET_VOIP	Edit	Delete

Set New WAN

Interface:

Mode:

Step 4: The following screen will appear, click on advance settings.

WAN Service

Connection Name:

Enable: ☒

MTU:

IP Protocol Type:

NAT: ☒

Firewall: ☒

IPv4 Static DNS: ☐

MAC Address Override: ☐

Enable VLAN: ☐

Service Type:

Advanced Settings

Apply Back Refresh

Step 5:

PIN: If the SIM card has a pin, please enter it into the PIN field or leave it blank if it does not have a PIN.

APN: Change it from auto to other, you will then have the option to enter the APN.

Advanced Settings

PIN:

NetWork:

APN:

DialNumber:

Dial UserName:

Dial Password:

DHCP Option 60 Setting: ☐

DHCP Option 66: ☐

DHCP Option 120: ☐

DHCP Option 81 Setting: ☐

Bound Ports: ☐ LAN1 ☐ LAN2 ☐ LAN3 ☐ LAN4
☐ SSID1 ☐ SSID2 ☐ SSID3 ☐ SSID4
☐ SSID5 ☐ SSID6 ☐ SSID7 ☐ SSID8
A grey out port means it has been bound.

Apply Back Refresh

Once you have entered the APN, click on apply. Give it a minute, if the internet still does not come through, power off the router, and turn it back on. The internet should come through.