

## [Basic Manual Setup for DWR-957X – Router login password]

**Step 1:** Open your web browser and type **10.0.0.2** into the address bar, then press Enter.



If your device is connected to the router, it will take you to a blue D-Link page asking for a username and password. Default Username is admin, password is admin, unless it was updated.



**Step 2:** Once logged in, navigate to

**Management → Account Management → Password**



**Step 3:** Here you will have the option to create a new password. Click on apply once done, the router will log out and you will have to use the new password to log back in.

## Account Management - Passwords

**Note:** Password cannot contain a space.

Username:

Old Password:

New Password:

Confirm Password:

Apply

Refresh