


DFL-210/260, DFL-800/860, DFL-1600/2500 How to setup IPSec VPN connection

This setup example uses the following network settings:




In our example the IPSec VPN tunnel is established between two LANs: 192.168.0.x and 192.168.1.x.
NOTE: It is essential to have private networks (LAN 1 and LAN 2) on different subnets.

Configuration of the Firewall on LAN 1

Step 1. Log into the Firewall by opening Internet Explorer and typing the LAN address of the Firewall. In our example we are using the default 192.168.1.1. Enter Username and Password which you specified during the initial setup of the Firewall.


Step 2. Go to Objects > Address Book > Interface Addresses. Click on Add and select "IP address".




Specify the settings of the remote network on the other end of the VPN tunnel.

Under Name enter "VPN-Remote-LAN".

Under IP Address enter the Subnet ID and Mask Bits for the remote network: in our example it is 192.168.0.0/24. Click on the OK button.



Step 3. Add another “IP Address”. Enter the settings of the VPN endpoint, the public IP address of LAN 2. Under Name enter “VPN-Remote-IP”. Under IP address specify the public IP address of the remote network (the IP address assigned by the ISP).




Dynamic IP Address: If remote network has dynamic public IP address, you can utilize one of the “Dynamic DNS” services available on the Internet. In this case the dynamic IP address of the remote site will be associated with a URL. To specify a URL as an address use this format: **dns:yoursite.dyndns.org**. Type the required URL under Interfaces > IPsec

Tunnels > ‘your tunnel settings’ > Remote Endpoint (**Step 5**).

To configure the VPN firewall to update one of the Dynamic DNS services go to System > Misc. Clients > Add... When setting up IPsec VPN Tunnel (**Step 5**) which connects to a site with dynamic IP address or accepts connections from roaming IPsec clients with dynamic IP addresses, set Remote Network as “Any” and Remote Endpoint as “None”.

Step 4. Go to Object > Authentication Objects > Click on Add and select Pre-Shared Key.




Enter the Pre-Shared Key settings for your VPN tunnel.


Under Name type "Pre-Shared-Key".

Under Shared Secret select the type of key you want to use and type in the key. In our example we are using ASCII key (passphrase). Note that you will need to use exactly the same key when setting up the firewall on the other end of the tunnel.

Click OK when done.



Step 5. Go to Interfaces > IPsec. Click on Add and select IPsec Tunnel.



Enter your IPsec tunnel settings.

Under Name enter "IPsec-tunnel".

Under Local Network select "lanet" (this is the private network on this side of the VPN tunnel).


Under Remote Network select "VPN-Remote-LAN" (this is the private network on the other side of the VPN tunnel, see **Step 2**).

Under Remote Endpoint select "VPN-Remote-IP" (this is the public up of the remote network, see **Step 3**).


Encapsulation Mode should be set to Tunnel.

Under Algorithms select the desired algorithms and IKE/IPsec lifetime. In our example we are using "Medium" settings.


You can modify or add your own set of security algorithms under Objects > VPN Objects > IKE Algorithms and IPsec Algorithms.




Click on Authentication tab. Make sure the Pre-Shared Key option is enabled. Select the “Pre-Shared-Key” in the dropdown menu (see **Step 4**).
Click on the OK button.




If the WAN port of the firewall is set with PPPoE authentication, select Advanced tab and change the Route Metric for the IPsec Tunnel to 80.




Step 6. Go to Interfaces > Interface Groups. Click on Add and select Interface Group.



Create a group which has your IPsec tunnel and your LAN.
Under Name type IPsec-LAN.
Under Interfaces add "IPsec-tunnel" and "lan" into Selected field.
Click on the OK button.



Step 7. Go to Rules > IP Rules. Click on Add and select IP Rule.



This rule will allow communication between the LAN and the IPsec tunnel.

Under Name type "IPSec-Allow".


Under Action select "Allow".

Under Service select "all_services".


Under Address Filter specify the following:

Source and Destination Interfaces: "IPSec-LAN" (this is the group you created in **Step 6**).


Source and Destination Network: select "all-nets".




Click on Log Settings tab.
Select the Enable Logging option.
Click on the OK button when done.



Step 8. Save the new configuration. In the top menu bar click on Configuration and select “Save and Activate”.



Click on OK to confirm the new settings activation:



Wait 15 seconds for the Firewall to apply the new settings.

Configuration of the Firewall on LAN 2

The steps to configure the second firewall will be almost identical to the steps for the firewall on the LAN 1. The only exception is the “Remote Network” and the “Remote Endpoint” settings. Note that the subnets on each LAN connecting through VPN should be different.

Step 1. Log into the Firewall on LAN 2. In our example we are using 192.168.0.1 address. Enter Username and Password which you specified during the initial setup of the Firewall.

Step 2. Go to Objects > Address Book > Interface Addresses. Click on Add and select “IP4 Host/Network”. Specify the settings of the remote network on the other end of the VPN tunnel.
Under Name enter “VPN-Remote-LAN”.

Under IP Address enter the Subnet ID and Mask Bits for the remote network: in our example it is 192.168.1.0/24. Click on the OK button.

Step 3. Add another “IP4 Host/Network”. Enter the settings of the VPN endpoint, the public IP address of LAN 1. Under Name type “VPN-Remote-IP”.

Under IP address specify the public IP address of the remote network (the IP address assigned by the ISP).

Step 4. Go to Object > VPN Objects > Pre-Shared Keys. Click on Add and select Pre-Shared Key. Enter the Pre-Shared Key settings for your VPN tunnel.

Under Name type “Pre-Shared-Key”.

Under Shared Secret select the type of key you want to use and type in the key. In our example we are using ASCII key (passphrase). Note that it should be exactly the same key you set up on the LAN 1 firewall. Click OK when done.

Step 5. Go to Interfaces > IPSec Tunnels. Click on Add and select IPSec Tunnel.

Enter your IPSec tunnel settings.

Under Name enter “IPSec-tunnel”.

Under Local Network select “lan1net” (this is the private network on this side of the VPN tunnel).

Under Remote Network select “VPN-Remote-LAN” (this is the private network on the other side of the VPN tunnel, see Step 2).

Under Remote Endpoint select “VPN-Remote-IP” (this is the public up of the remote network, see Step 3).

Encapsulation Mode should be set to Tunnel.

Under Algorithms select the desired algorithms and IKE/IPSec lifetime. The settings should correspond with the settings on the remote VPN Firewall.

Click on Authentication tab. Make sure the Pre-Shared Key option is enabled. Select the “Pre-Shared-Key” in the dropdown menu (see Step 4). Click on the OK button.

Step 6. Go to Interfaces > Interface Groups. Click on Add and select Interface Group.

Create a group which has your IPSec tunnel and your LAN.

Under Name type IPSec-LAN.

Under Interfaces add “IPSec-tunnel” and “lan” into Selected field. Click on the OK button.

Step 7. Go to Rules > IP Rules. Click on Add and select IP Rule.

This rule will allow communication between the LAN and the IPSec tunnel.

Under Name type “IPSec-Allow”.

Under Action select “Allow”.

Under Service select “all_services”.

Under Address Filter specify the following:

Source and Destination Interfaces: “IPSec-LAN” (this is the group you created in Step 6).

Source and Destination Network: select “all-nets”.

Click on Log Settings tab.

Select the Enable Logging option.

Click on the OK button when done.

Step 8. Save the new configuration. In the top menu bar click on Configuration and select “Save and Activate”. Click on OK to confirm the new settings activation.

Wait 15 seconds for the Firewall to apply the new settings.

Connecting via VPN tunnel

To check the status of your VPN connection, click on Status and select IPsec. If the VPN tunnel is up, you will see an active entry under IPsec SAs.

The screenshot shows the D-Link web interface with the 'IPsec Status' page selected. The 'General' section shows the VPN interface is 'IPSec-tunnel'. Below this are two line graphs for 'Send rate over the past 24 hours' and 'Receive rate over the past 24 hours', both showing 0 kbps. At the bottom, there is a table of IPsec SAs:

Remote Gateway	Local Net	Remote net	Protocol
202.129.109.93	192.168.1.0/24	192.168.0.0/24	ESP: rijndael-cbc hmac-md5-96

In order to trigger the VPN firewall to establish VPN tunnel try accessing any IP address on the remote private network (e.g. ping an IP address on remote LAN).

If VPN Tunnel can not be established:


- Make sure that the modems in front of the firewalls support VPN passthrough.
- Check the Pre-shared keys, security algorithms and life times, make sure they match on both VPN firewalls.
- Restart both firewalls.

You can see the connection log under Status > Logging.

The screenshot shows the 'Log Status' page with a table of internal logging events. The table has columns for Date, Severity, Category, Rule, Proto, SrcIf, Srd/DstIP, Srd/DstPort, and Details. The events show various connection attempts and successful connections for the IPsec tunnel.

Date	Severity	Category	Rule	Proto	SrcIf	Srd/DstIP	Srd/DstPort	Details
2006-05-19 00:36:33	Notice	CONN	IPSec-Allow	UDP	lan	192.168.1.2	1030	conndestif=IPSec-tunnel
2006-05-19 00:36:29	Notice	CONN	IPSec-Allow	ICMP	lan	192.168.1.2	53	connsrclid=512 conndestif=IPSec-tunnel conndestid=512 origsent=1680 termsent=1680
2006-05-19 00:36:12	Notice	CONN	IPSecBeforeRules	UDP	wan	202.129.109.93	500	conndestif=core origsent=7748 termsent=0
2006-05-19 00:35:53	Notice	CONN	IPSec-Allow	ICMP	lan	192.168.1.2	53	connsrclid=512 conndestif=IPSec-tunnel conndestid=512
2006-05-19 00:35:35	Notice	CONN	IPSec-Allow	ICMP	lan	192.168.1.2	53	connsrclid=512 conndestif=IPSec-tunnel conndestid=512 origsent=60 termsent=0
2006-05-19 00:35:26	Notice	CONN	IPSec-Allow	ICMP	lan	192.168.1.2	53	connsrclid=512 conndestif=IPSec-tunnel conndestid=512
2006-05-19 00:34:15	Notice	CONN	IPSec-Allow	UDP	lan	192.168.1.2	1028	conndestif=IPSec-tunnel
2006-05-19 00:33:59	Informational	IPSEC						SA ESP[b570dac] alg [rijndael-cbc/16]+hmac[hmac-md5-96] bundle [4,0] pri 0 opts src=ipv4_subnet(any:0,[0..7]=192.168.0.0/24) dst=ipv4_subnet(any:0,[0..7]=192.168.1.0/24)
2006-05-19 00:33:59	Informational	IPSEC						SA ESP[9e022db6] alg [rijndael-cbc/16]+hmac[hmac-md5-96] bundle [4,0] pri 0 opts src=ipv4_subnet(any:0,[0..7]=192.168.1.0/24) dst=ipv4_subnet(any:0,[0..7]=192.168.0.0/24) Phase-2 [responder] done bundle 4 with 2 SAs by rule 1: 'ipsec ipv4_subnet(any:0,[0..7]=192.168.1.0/24)->ipv4_subnet(any:0,[0..7]=192.168.0.0/24)(gw:ipv4(any:0,[0..3]=202.129.109.93))'
2006-05-19 00:33:45	Notice	CONN	IPSec-Allow	TCP	lan	192.168.1.2	4943	conndestif=IPSec-tunnel origsent=790 termsent=1136
2006-05-19 00:33:16	Notice	CONN	IPSec-Allow	TCP	IPSec-tunnel	192.168.0.149	3844	conndestif=lan origsent=168 termsent=404

To connect to shared resources via VPN you can map remote computers' drives and folders by opening Windows Explorer and going to Tools > Map Network Drive (you need to specify the IP address of the computer on remote network and the name of the shared folder):



Alternatively you can do Search > Computers or People > Computer on Network > specify the IP address of the computer you are trying to connect to.
If you do not see computers in My Network Places or My Network Neighbourhood you may need to enable NetBIOS over TCP/IP in Windows.
Note that firewall/antivirus software installed on your or remote computer may stop you from accessing remote network.