

How to configure DNS Relay

This example describes about firewalls support to relay DNS query packets from LAN to Internet for domain name resolving. All DFL firewalls (DFL-210/800/1600/2500) support this feature from firmware v2.04 and later.

Note: About this feature, it performs relay/forward DNS packets only since D-Link DFL firewalls don't built-in DNS server in system kernel. Therefore, it can not instead of real DNS server to provide domain name resolving and related functionality.

Details:

- LAN IP on firewall: 192.168.1.1 (with the function of DNS relay)
- Lannet on firewall: 192.168.1.0/24
- DNS Server on Internet: 12.0.0.1

1. Addresses

Go to *Objects -> Address book -> InterfaceAddresses*

Create an IP Address called dns_server with address 12.0.0.1

Click Ok.

2. Create IP Rules to redirect DNS packets to Internet

Go to *Rules -> IP Rules*

Create a new IP Rule with SAT action.

In the General tab:

General:

The screenshot shows the 'General' tab of an IP rule configuration window. At the top, there is a traffic light icon with red, yellow, and green lights. Below it, a descriptive text reads: "An IP rule specifies what action to perform on network traffic that matches the specified filter criteria." The configuration fields are as follows:

Name:	SAT_DNS_Relay
Action:	SAT
Service:	dns-all
Schedule:	(None)

Name: **SAT_DNS_Relay**

Action: **SAT**

Service: **dns_all**

Address Filter:

The screenshot shows the 'Address Filter' configuration window. It includes a note: 'Specify source interface and source network, together with destination interface and destination network. All parameters must match the rule to match.' Below this, there are two sections: 'Source' and 'Destination'. Under 'Source', 'Interface' is set to 'lan' and 'Network' is set to 'lannet'. Under 'Destination', 'Interface' is set to 'core' and 'Network' is set to 'lan_ip'.

Source Interface: **lan**
 Source Network: **lannet**
 Destination Interface: **core**
 Destination Network: **lan_ip**

In the SAT tab:

The screenshot shows the 'IP Rule' configuration window with the 'General' tab selected. The 'General' section contains settings for translating destination IP addresses. It shows 'Translate the' set to 'Destination IP Address', 'To:' set to 'dns_server', and 'New Port:' left empty. A note indicates that port numbers or ranges must be entered without gaps. There is also an unchecked checkbox for 'All-to-One Mapping'.

Translate the: **Destination IP Address**
 New IP Address: **dns_server**

Click Ok.

Create an identical IP Rule with NAT action. If the environment is not NAT, create a ALLOW rule instead.

In the General tab:

Name:	Allow_DNS_Relay
Action:	NAT
Service:	dns-all
Schedule:	(None)

Name: **Allow_DNS_Relay**

Action: **NAT**

Service: **dns_all**

Address Filter:

Source	Destination
Interface: lan	core
Network: lannet	lan_ip

Source Interface: **lan**

Source Network: **lannet**

Destination Interface: **core**

Destination Network: **lan_ip**

Click Ok.

Make sure these two rules are triggered before any generic rules (e.g. allow_standard rules).

And also, configure all PCs to have the firewall lan_ip (192.168.1.1) as DNS server.

Save and activate the configuration on firewall