

D-Link[®] Quick Installation Guide

This product can be setup using any current web browser, i.e., Internet Explorer 6 or Netscape Navigator 7.0



DP-G301
AirPlus™ G 2.4GHz
Wireless Print
Server

Before You Begin

You will need an Ethernet-enabled device, such as a laptop or desktop computer and a parallel port printer that will connect to the DP-G301.

Important: TURN OFF the power to the printer before installing the DP-G301.

Check Your Package Contents



DP-G301 AirPlus™ G Wireless parallel port Print Server



CD-ROM (Software, Manual and Warranty)



5V DC 2.5A Power Adapter




Using a power supply with a different voltage rating will damage this product and void its warranty.

If any of the above items are missing, please contact your reseller.

1

Connecting The DP-G301 To Your Network

First, insert one end of a straight-through CAT5 Ethernet RJ-45 cable into the “Network Port” (shown below.) Connect the other end of the cable to the LAN port of the gateway or switch. *Note: Do not connect the power cord to the DP-G301 until you are advised to do so.*




Warning!

Only a parallel port printer may be connected to the parallel port of the DP-G301. Do not connect any other parallel port device to the parallel port; doing so may damage the unit, voiding the warranty for this product.

Next, make sure that the printer is turned **OFF**.

Connect the parallel port of the DP-G301 (shown below) to the parallel port of the printer. Turn **ON** the printer.



Then, plug one end of the power adapter into the DP-G301 and the other end into your electric outlet. The DP-G301 will turn on and begin a self-test.



For Mac OS printing, please refer to manual (.pdf) located on the CD-ROM.

2

Setting up your DP-G301 for network printing in Windows XP


For additional Windows operating system setup or information on the web-management interface, refer to the manual located on the CD-ROM.

The factory default IP address of the DP-G301 is 192.168.0.10. In order to network to the printer through the DP-G301, the DP-G301 must have the same IP network settings as your network. IP address can be assigned manually or automatically by DHCP, BOOTP or RARP. To access the print server's web configuration, manually assign an IP address on one of the wired PC's on your network to the same subnet as the print server.

Go to **Start > right click on My Network Places > select Properties > Double-click on the Network Connection** associated with your Network Adapter.

Click **Internet Protocol (TCP/IP)**

Click **Properties**




Input a static IP address in the same range as the print server.

Select **Use the following IP address**

IP address: **192.168.0.52**
Subnet mask: **255.255.255.0**

Click **OK**




2

Setting up your DP-G301 for network printing in Windows XP (continued)


**Note: Please notice that if you connect your printer server in a LAN where a DHCP server is present. The IP address will differ from the one in the example 192.168.0.10.*

Click OK to apply IP address settings.




Click **OK**

Using your web browser enter the IP address of the DP-G301. By default the IP address is set to **192.168.0.10**



The IP address of the DP-G301 can be modified on the **Network** tab of the web configuration menu.

The following instructions use the print server's default IP address as an example. Make the appropriate changes if you modify the DP-G301's IP address.



2

Setting up your DP-G301 for network printing in Windows XP (continued)

Click on the **Configuration** tab to view the current **Wireless Settings**.




1 Select your **Connection Mode**

2 Enter the **SSID** of the remote access point or wireless router you wish to connect to.

3 If you would like to set **WEP Encryption**, select the encryption level and the key here.

Click on the **System** tab to view the current **Port Settings**.



⚠ Write down on a piece of paper the Port name that you wish to use.

1 **What is Infrastructure and Ad-Hoc Mode?**
Ad-Hoc: Refers to two or more 802.11b wireless devices that communicate directly with one another without using an access point or any connection to a wired network.
Infrastructure: Refers to an 802.11 network in which wireless devices communicate with each other by first going through an Access Point (AP) or wireless router.

2 **What is an SSID?**
A workgroup name of your Wireless Network. All wireless devices must all have the same SSID to communicate on the Wireless Network. All D-Link Wireless devices have the default SSID of default, all lower case.

3 **How does WEP Work?**
64 bit WEP encryption uses a 10 hexadecimal character key. **128 bit WEP** uses a 26 hexadecimal character key. The WEP encryption key must match the WEP settings on your AP or wireless router to connect properly.

2

Setting up your DP-G301 for network printing in Windows XP (continued)

For Windows XP:

Go to Start>Printers and Faxes>Add a Printer or Go to Start>Control Panel>Printers and Faxes




Double-click on the "Add Printer" icon



Click Next

Select "Local Printer."

Please make sure to deselect **Automatically detect and install my Plug and Play printer.**




Click Next

2

Setting up your DP-G301 for network printing in Windows XP (continued)

Select **“Create a new port.”**
At the pull-down menu, highlight **“Standard TCP/IP Port.”**

Click **Next**



Click **Next**




Type in the IP address of the print server. (i.e. 192.168.0.10)
The port name will automatically be filled in.

Click **Next**



This may take a few seconds




2

Setting up your DP-G301 for network printing in Windows XP (continued)

Select **“Custom”**
Then click on **Settings**.


Click **Settings**




Select **“LPR”**

Input the port name of the port being used by the printer

Click **OK**




Click **Next**




2

Setting up your DP-G301 for network printing in Windows XP (continued)




Click **Finish**

In this window, scroll down to find your printer. (If it is not listed, insert the driver CD or diskette that came with your printer.) Click on **“Have Disk...”** Then, scroll down and highlight the printer.



Click **Next**


At this screen, you can input a name for this printer.



Click **Next**

2 Setting up your DP-G301 for network printing in Windows XP (continued)

Select “Yes” to print a test page



3 Your Setup is Complete!

The printer is now ready for printing with Windows XP, on your network.



Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within Australia:

D-Link Technical Support over the Telephone:

1300-766-868

Monday to Friday 8:00am to 8:00pm EST

Saturday 9:00am to 1:00pm EST

D-Link Technical Support over the Internet:

<http://www.dlink.com.au>

email:support@dlink.com.au

Tech Support for customers within New Zealand:

D-Link Technical Support over the Telephone:

0800-900-900

Monday to Friday 8:30am to 8:30pm

Saturday 9:00am to 5:00pm

D-Link Technical Support over the Internet:

<http://www.dlink.co.nz>

email:support@dlink.co.nz



Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within South Eastern Asia and Korea:

D-Link South Eastern Asia and Korea Technical Support over the Telephone:

+65-6895-5355

Monday to Friday 9:00am to 12:30pm, 2:00pm-6:00pm
Singapore Time

D-Link Technical Support over the Internet:

email: support@dlink.com.sg

D-Link[®]
Building Networks for People

Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within India

D-Link Technical Support over the Telephone:

+91-22-26526741

+91-22-26526696 –ext 161 to 167

Monday to Friday 9:30am to 7:00pm

D-Link Technical Support over the Internet:

<http://www.dlink.co.in>

<http://www.dlink.co.in/dlink/drivers/support.asp>

<ftp://support.dlink.co.in>

email: techsupport@dlink.co.in

D-Link[®]
Building Networks for People

Technical Support

You can find software updates and user documentation on the D-Link website.

D-Link provides free technical support for customers for the duration of the warranty period on this product.

Customers can contact D-Link technical support through our website or by phone.

Tech Support for customers within the Russia

D-Link Technical Support over the Telephone:

(095) 744-00-99

Monday to Friday 10:00am to 6:30pm

D-Link Technical Support over the Internet:

<http://www.dlink.ru>

email: support@dlink.ru



Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within the U.A.E & North Africa:

D-Link Technical Support over the Telephone:

(971) 4-391-6480 (U.A.E)

Sunday to Wednesday 9:00am to 6:00pm GMT+4

Thursday 9:00am to 1:00pm GMT+4

D-Link Middle East & North Africa

D-Link Technical Support over the Internet:

<http://support.dlink-me.com>

email: support@dlink-me.com

Tech Support for customers within Israel:

D-Link Technical Support over the Telephone:

(972) 971-5701

Sunday to Thursday 9:00am to 5:00pm

D-Link Technical Support over the Internet:

<http://www.dlink.co.il/forum>

e-mail: support@dlink.co.il

Tech Support for customers within Turkey:

D-Link Technical Support over the Telephone:

(+90) 212-289 56 59

Monday to Friday 9:00am to 6:00pm

D-Link Technical Support over the Internet:

<http://www.dlink.com.tr>

e-mail: turkiye@dlink-me.com

Tech Support for customers within Egypt:

D-Link Technical Support over the Telephone:

(202) 414-4295

Sunday to Thursday 9:00am to 5:00pm

D-Link Technical Support over the Internet:

<http://support.dlink-me.com>

e-mail: amostafa@dlink-me.com

D-Link®
Building Networks for People

Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within South Africa and Sub Sahara Region:

D-Link South Africa and Sub Sahara Technical Support over the Telephone:

+27-12-665-2165

08600 DLINK (For South Africa only)

Monday to Friday 8:30am to 9:00pm South Africa Time

D-Link Technical Support over the Internet:

<http://www.d-link.co.za>

email:support@d-link.co.za



Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for Latin America customers:

D-Link Technical Support over the followings Telephones:

Argentina: 0800-666 1442	Monday to Friday 09:00am to 22:00pm
Chile: 800-214 422	Monday to Friday 08:00am to 21:00pm
Colombia: 01800-700 1588	Monday to Friday 07:00am to 20:00pm
Ecuador: 1800-777 711	Monday to Friday 07:00am to 20:00pm
El Salvador: 800-6137	Monday to Friday 06:00am to 19:00pm
Guatemala: 1800-300 0017	Monday to Friday 06:00am to 19:00pm
Panama: 0800-560 0193	Monday to Friday 07:00am to 20:00pm
Peru: 0800-52049	Monday to Friday 07:00am to 20:00pm
Venezuela: 0800-100 3470	Monday to Friday 08:00am to 21:00pm

D-Link Technical Support over the Internet:

www.dlinkla.com
www.dlinklatinamerica.com
email:support@dlink.cl

Tech Support for customers within Brazil:

D-Link Technical Support over the Telephone:

0800-7014104
Monday to Friday 8:30am to 18:30pm

D-Link Technical Support over the Internet:

www.dlinkbrasil.com.br
email:suporte@dlinkbrasil.com.br

D-Link®
Building Networks for People